

Repairing small scrapes and dings in a finished floor

1. Mark the areas that need repair
2. Determine if the basecoat is in place and still adhered.
3. Remove any loose coating either by sanding or cutting.
4. Using a sandpaper scuff the area to be repaired and the immediate edge around it.
5. Wipe away any debris and use some acetone on a rag if needed to clean.
6. If Basecoat is in place and adhered:
 - a. Mix a small amount of Topcoat to do the repairs.
7. If Basecoat is NOT in place and adhered:
 - a. Mix a small amount of Basecoat to do the repairs.
8. Using a small brush lightly coat the repair area (Avoid the surrounding edges when possible)
9. Apply chip by rubbing it between your hands to create a uniform look to the floor.
10. Press the chip down with a gloved hand to flatten and encapsulate into the repair product.
11. Cure times will vary by temperature and humidity- allow enough time to be able to scrape.
12. Scrape aggressively with a putty knife to make the repair area as smooth as possible.
13. Clean the area of any loose chip and make sure the area is completely fixed.
14. Mix a small amount of Topcoat.
15. Using a small brush apply Topcoat to the repair.
16. Use enough to soak into the chips and lightly coat the scuffed edge.
17. Dab away any excess product with a rag (leaving a puddle will have an unwanted appearance)
18. Lightly touch the topcoat with a rag to remove some of the gloss.
19. Mask the area so your customer avoids walking or driving on the repair for 24 hours.